

接触器部分上端

KM1-53NO	KM1-61NC	KM1-A1	KM1-L1	KM1-L2	KM1-L3	KM1-71NC	KM1-83NO	

接触器部分下端

KM1-54NO	KM1-62NC	KM1-T1	KM1-T2	KM1-T3	KM1-A2	KM1-72NC	KM1-84NO	

